
REPLACEMENT PARTS - MODEL CC4105 4-CYCLE GAS TRIMMER

PPN 41ADC05G912




REPLACEMENT PARTS - MODEL CC4105 — 4-CYCLE GAS TRIMMER

PPN 41ADC05G912

<u>Item</u>	Part No.	<u>Description</u>	<u>Item</u>	Part No.	Description
1	753-05449	Engine Cover	30	753-05446	Clutch Cover Assembly (includes 31-33)
2	791-181345	Screw	31	791-181345	Cover Screw
3	753-05377	Screw	32	791-182519	Anti-Rotation Screw
4	753-05209	Valve Cover	33	753-04291	Clamping Screw Assembly
5	753-05210	Valve Cover Gasket	34	753-05447	Ignition Module Assembly
6	753-05438	Cylinder Assembly (includes 5, 7 & 40)	35	791-610303	Square Nut Drive
7	791-181003	Cylinder Screw	36	753-05240	Flywheel
8	753-05247	Insulator Gasket	37	791-181861	Shroud Screw
9	753-05248	Nut	38	753-04919	Cam Bracket Assembly (includes 39)
10	753-05452	Insulator (includes 11)	39	791-181012	Cam Bracket Screw
11	753-05439	Carburetor Gasket	40	791-182374	Cylinder Gasket
12	753-05440	Carburetor w/Primer	41	791-182377	Oil Pan (includes 42 & 43)
13	791-181751	Carburetor O-Ring	42	791-181018	Oil Pan Gasket
14	753-05441	Air Filter Cover Assembly (includes 16)	43	791-181020	Oil Pan Screw
15	753-05253	Air Filter Mounting Screw	44	791-182378	Dipstick Assembly (includes 45)
16	753-05442	Air Filter	45	791-182290	O-Ring
17	753-05289	Fuel Cap	46	753-05458	Piston Assembly
18	791-181930	Screw	*	791-180852B	Spark Plug
19	791-182366	Clip Nut	*	753-05459	Shortblock Assembly (includes 3-7 & 34-46)
20	753-05443	Fuel Tank Assembly (includes 17)			
21	753-05444	Muffler Assembly (includes 22 & 23)			
22	753-05244	Muffler Gasket			
23	753-05246	Muffler Mounting Screw			
24	753-05264	Lead Wire			
25	753-05445	Starter Housing Assembly (includes 3, 19 & 26-29)			
26	753-1202	Plate Screw			
27	753-05260	Push Nut			
28	791-613103	Rope			
29	791-181079	Pull Handle			

REPLACEMENT PARTS - MODEL CC4105 4-CYCLE GAS TRIMMER

PPN 41ADC05G912



Optional Accessories

* 791-153577B Inner Reel & Line

* Items Not Shown